QUIC-ACCESS® FIRE Extinguisher Cabinet Model FECR

ZICO 5005PM4

REV. 6-20-12

Mounting Instructions

Protects fire extinguishers and keeps them ready for action.

Constructed of UV resistant fiberglass materials with highly visible red and white door. Stick-on labels indicate the type of fire extinguisher. Bulb seal gasket locks out moisture and dirt, while stainless steel hinge and latches are highly resistant to corrosive chemicals. Without opening the cabinet door, the sight window allows external visual inspection of contents. ZICO wall cabinet accommodates nearly any brand or size of fire extinguisher and may be flush mounted or wall hung.



		OUTSIDE DIMENSIONS	INSIDE DIMENSIONS	WT./@
ORDER NO.	DESCRIPTION	WxHxD	WxHxD	IN LBS.
FECR	Fire Extinguisher Cabinet	15-1/2" x 27" x 11"	13" x 26" x 9-1/4"	14.5

Please read mounting instructions carefully before mounting your new cabinet.

- 1. Place the cabinet on a work bench and place the fire extinguisher onto the bottom shelf of the cabinet, centered.
- 2. If the extinguisher is provided with a mounting slot, the bracket may be attached in place of supplied bracket. Place the bracket above the mounting slot and mark the mounting holes.
- 3. To use supplied bracket, drill three holes for 1/4-20 hardware and mount the bracket. Use bracket as template.
- 4. Remove fire extinguisher and place cabinet against the surface upon which it is to be mounted.
- 5. Bottom of cabinet should be approximately 36" above the floor level.
- 6. Drill four 5/16" holes through the cabinet, one in each corner, and into the mounting surface. If sheet metal or wood screws are to be used for mounting, use a 1/4" drill.
- 7. Fasten cabinet to mounting surface (hardware not provided).
- 8. Place the fire extinguisher into the cabinet.

Ziamatic Corp.

www.ziamatic.com TOLL FREE: 800-711-3473

10 West College Avenue, P.O. Box 337, Yardley, PA 19067-0587 • (215) 493-3618 • FAX: (215) 493-1401